

Installation Process

1. Before installation



2. Adjusting the position of reinforcing rod



Check the anchor position by adjusting the position of reinforcing rods before fitting anchor bolts

3. Setting fixed guide



Decide the shape and number of anchor bolts by calculating structural strength and fitting with corrosion treatment.

4. Setting the control gate



Combine to the fixed guide. Metal fittings for vibration isolation

Setting the control gate and prevention of leakage

5. Installing hydro turbine unit



Lifting to install the system



Adjust by horizontality, height, and direction.

6. Setting flow control adjustment



Flow control adjustment



7. Setting the screen



8. Starting generation

